

STEP 1:

Use the original screws of the car to fix the bracket to the hood

STEP 2:

Fix the one end of the Gas Strut on the bracket, put on the shim and tighten the screw



STEP 3:

Fix the other end of the Gas Strut to the original hole of the car

