



- 1, Remove the 3 Bolts connecting EGR Cooler to Exhaust manifold.
- 2, Loosen the mounting Bolt of the EGR Cooler.
- 3, Apply silicon sealant around edges of EGR Blanking Plate.
- 4, Slide the EGR Blanking plate in on Cooler side of metal gasket.
- 5, Replace 3 Bolts and tighten.
- 6, Tighten mounting Bolt.