



Needle Valve



Boost Adjustment



To Adjust a Dawes Valve
(1) Undo the thin locknut

**(3) Adjust the Valve
length with a spanner**

**(2) Hold the knurled
ring with pliers**

Dawes Valve

Damper

**Air
Pipe**

Vacuum Pipe






Tee

Boost Line

Air
Pipe

Vacuum
Pipe





PCV Hoses

Catch Can

Vacuum
Pipe

Air
Pipe



Air Line To Needle Valve

Air Filter Resonator

Block off Ports

Boost Control Solenoid