


TOYOTA HILUX

1KD-FTV 3.0L D4D TDI / 4.0L V6 PETROL



LOCATION



FITTING INSTRUCTIONS

Unplug the diesel computer and remove the computer with the original bracket attached.

Re-fit the diesel computer to the supplied bracket using 3 x original screws as per Fig 1.

Attach the computer bracket to the battery tray using 2 x M6 countersunk bolts and 2 x locknuts as per figure 2.

Place new battery tray into position and align with 3 x fixed nuts and 2 x original bolt holes. Secure with bolts and washers supplied. **NOTE: from 2010 models on you may need to insert a spacer washer under the rear mount.**

Insert battery into tray and secure in place using the top battery bracket supplied as per Figure 5.

Clamp the battery down using the 2 x galvanised J-Bolts and nuts supplied. **DO NOT OVER TIGHTEN.** The J-Bolts should be tightened down evenly until the battery does not move when twisted.

Use the 2 x galvanised spacer washers to mount the top bracket to the guard. Space to suit the height of your battery and secure with the longer M6 bolt supplied.

IT IS CRITICAL THAT THE TOP BATTERY BRACKET IS SECURED AT THE ANCHORE POINT ON THE PASSENGER SIDE GUARD. FAILURE TO SECURE THE BATTERY AT THIS POINT CAN RESULT IN DAMAGE TO THE VEHICLE.

PARTS LIST